



Propane Patio Heater

Please review these instructions before operating the equipment.

BEFORE YOU BEGIN Patio heater • Propane tank • Ignitor / control knob • Outdoor area

1 SETUP

- Place the heater outdoors on a stable, level surface with appropriate clearance from combustible materials.
- Securely connect the propane tank and open the tank valve.

2 LIGHTING

1. Turn the control knob to PILOT.
2. Press and hold the knob for approximately 45–60 seconds.
3. While continuing to hold the knob, press the ignitor until the pilot lights.
4. Continue holding the knob for approximately 10 seconds after ignition.
5. Release the knob and adjust to the desired heat setting.

If the pilot does not light, turn the controls off and follow the relighting instructions provided with the unit.

3 IMPORTANT

- Patio heaters are intended for appropriate outdoor use.
- Keep appropriate clearance from tents, linens, décor and combustible materials.
- Never leave a lit heater unattended.
- Do not move the heater while it is lit or hot.

4 AFTER USE & RETURN

- Turn the heater off.
- Close the propane tank valve.
- Allow the heater to cool completely.

HAVING A PROBLEM? CALL US RIGHT AWAY: 305-969-1025

Stop using the equipment and contact Christina's Party Rentals as soon as an issue is discovered.

We can assist by phone or, when appropriate and available, dispatch a technician to your event.

Service calls are subject to availability, location and timing. If a technician is dispatched and the equipment is found to be operating properly and the issue is determined to be user error, additional service fees may apply.