



Propane Stove & Oven Range

Please review these instructions before operating the equipment.

BEFORE YOU BEGIN Range • Propane tank • Oven controls • Stovetop burners

1 BEFORE USE

- Make sure all stove and oven controls are in the OFF position.
- Securely connect the propane tank before opening the tank valve.

2 OVEN

Follow the lighting instructions provided with the rented unit to ignite the oven pilot before setting the desired temperature.

3 STOVETOP

Light each burner carefully according to the provided instructions, then adjust the burner to the desired flame level.

4 AFTER USE & RETURN

- Turn all burners and oven controls to OFF.
- Close the propane tank valve.
- Allow the entire unit to cool completely.
- Remove food, grease and debris before pickup.

HAVING A PROBLEM? CALL US RIGHT AWAY: 305-969-1025

Stop using the equipment and contact Christina's Party Rentals as soon as an issue is discovered.

We can assist by phone or, when appropriate and available, dispatch a technician to your event.

Service calls are subject to availability, location and timing. If a technician is dispatched and the equipment is found to be operating properly and the issue is determined to be user error, additional service fees may apply.