

CHAFERS AND URNS

Chafing Dish and Urn (Canned Heat)

1. Use only canned fuel in the burner.
2. Fill the water pan, urn or kettle before lighting the burner.
3. Low flame is sufficient to maintain proper heat.
4. Keep away from open flame or hot stove.
5. Stainless steel food pans can be used for cooking and/or placed in the oven to retain heat.
6. Fill chafing dish with hot water.
7. Check pan during use to maintain sufficient water level. **DO NOT USE WITHOUT WATER!**

Use of Canned Heat

Pry the lid from the canned heat, and place canned heat into heat cup. Light fuel, adjusting the lid to approximately half-open.

Cleaning Instructions

Scrape and wash food pans in lukewarm water using mild detergent, never harsh abrasives.

These guidelines and tips are common-sense suggestions designed to promote chafing dish / urn efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of chafing dishes / urns. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measures to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Christina's Party Rentals disclaims all liability for, and makes no warranty or guarantee of, the accuracy or applicability of this information in any situation.

CHRISTINA'S PARTY RENTALS
9740 EAST EVERGREEN STREET
MIAMI, FL 33157
TEL: 305-969-1025 – FAX: 305-969-1622
www.christinaspartyrentals.net